



7 - BJT Intro and Switching

Name: _____

In-Class Problems

(1) For a PNP BJT, the emitter is typically p+ and the base lightly doped n-type. This is one of the factors that helps a small base current cause a large emitter-to-collector current. See the equations below for when we derived the diode current equation.




(a) for the p+n diode parameters listed below, in forward bias, how many more holes are injected to the right vs. electrons injected toward the left? *Hint: just divide J_p/J_n , eliminate common terms, and give me the ratio between the two. Remember, it should show us LOTS of hole current vs. very small electron current (so we can get amplification).*

p-side:	n-side:
$N_a = 10^{17}/\text{cm}^3$	$N_d = 10^{15}/\text{cm}^3$
$n_p = 2.25 \times 10^3/\text{cc}$	$p_n = 2.25 \times 10^5/\text{cc}$
$D_n = 18 \text{ cm}^2/\text{sec}$	$D_p = 25 \text{ cm}^2/\text{sec}$
$L_n = 10^{-3} \text{ cm}$	$L_p = 10^{-2} \text{ cm}$

$$J_p(x_n = 0) = q \frac{D_p}{L_p} p_n (e^{qV/kT} - 1)$$

$$J_n(x_p = 0) = -q \frac{D_n}{L_n} n_p (e^{qV/kT} - 1)$$

(b) wait? We will take this same BJT problem next class, and calculate amplification factor, and find out that it will be in the hundreds. How can that be then? For part (a) above, you will find J_n is only about 13X less than J_p , so that would be an amplification factor at best of 13? Right? What is going on?! See if you can figure it out. Look at the diagram below, the diagram is for diode with n and p regions that are LONG on both sides. *Hint, remember for a carrier to either drift, or diffuse over, it has to be roughly within a diffusion length of the depletion region (if not, it recombines before it can make it across).* So for a BJT, in the base region, are we able to tap into all the electrons that could diffuse over for a normal diode, or not? Often W_b is $\sim 1 \mu\text{m}$ and L_n is often $100 \mu\text{m}$ or more!



SECS 2077 - Semiconductor Devices Homework

(c) so now we have LOTS holes injecting from the p+ emitter into the lightly doped n-type base, and it required very few electrons to be injected from the base to the emitter. Next we need to add a collector and to have a narrow base (see diagram at right). As holes try to make it across the base to the collector, explain why we need to have a narrow base.

(d) for your answer to (b), does having a lightly doped base also help in the same way?

(2) Draw the band-diagram shown for question 1. Make sure the Fermi level positions are like that shown (represent the doping levels). Then...

(a) Label each region (emitter, base, and collector) using only these voltages as options (0V, +1V, -4V) as they would be under normal active mode (small base current being amplified into a large collector current). *The voltages are not in the right order above, you have to figure out the order!*

(b) Draw with up or down arrows, how the bands are relatively shifted by applied voltage.



(c) Lastly, label the three major drivers of hole current across the BJT as DIFFUSION or DRIFT. These regions are emitter-to-base, across the base, and base-to-collector. Make sure you understand why for each also!

(d) See the spec sheet I-V curves below. Why is I_C exponential vs. V_{BE} ? The answer is simple. (ignore the temperature dependences, we will discuss that later).

(e) See the spec sheet I-V curves below. For I_C vs. V_{CE} , what is the amplification factor (Beta)? To be sure, pick 2 or 3 base-currents and collector currents to calculate Beta.


(f) See the spec sheet I-V curves below. As V_{CE} is increased it takes a little bit (looks like $\sim 0.5V$) to get the BJT amplification going. Question: basically all the V_{CE} voltage drop occurs where in the BJT? ... and why is the collector current fairly constant as V_{CE} is further increased?

(g) Discover ahead for yourself! Based on your answer to (f), that increasing V_{CE} should increase the base-collector depletion region, right? An increasing depletion region should cut into the base and reduce W_b (the un-depleted width of the n-type base). So, if increasing V_{CE} reduces W_b a bit, then why the slight positive slope for I_C vs. V_{CE} ?




(3) Consider a PNP BJT. Calculate and label the magnitudes of each current component on the diagram given the following.

- Amplification factor (β) ≈ 100
- Current transfer ratio (α) ≈ 0.99
- Emitter injection efficiency (γ) ≈ 1.00
- Base transport factor (B) ≈ 0.99
- Collector current (I_C) = 100 mA.



(4) Draw a common emitter PNP BJT circuit (see image at right for an example), and for V_{be} have a 10 k Ω resistor, and for V_{ce} have a 500 Ω output resistance. Assume the amplification factor is 100. If we apply 1 V to forward bias the emitter base, and 20 V across the emitter and collector to setup the base-collector as reverse biased, what will the voltage drop be:

- (a) across the output resistance;
- (b) across the reverse biased base-collector.



(5) Drift vs. diffusion in a BJT! Circle or underline all that apply.

- (a) type of current coming from the emitter: drift / diffusion / recombination
- (b) type of current coming out the collector: drift / diffusion / recombination
- (c) for a well designed BJT, dominates the base current: drift / diffusion / recombination
- (d) drives emitter to collector current across the base: drift / diffusion / recombination

(6) Consider an NPN BJT biased such for normal operation (base current amplified into larger emitter to collector current). Assume the emitter is heavily doped and the base and collector lightly doped.

- (a) [5 pts] draw a band diagram for an NPN BJT (not PNP like we did in class). Include Fermi levels and indicate voltage drops using the offsets between Fermi levels. Label the E, B, and C, regions.
- (b) [5 pts] label the direction of emitter to collector current (remember e's move in opposite direction of current flow)
- (c) [5 pts] for electron current, label where they are driven by a concentration gradient (CG), where they are driven by electric field (EF), and where it is caused by recombination (R).